

Dane aktualne na dzień: 08-10-2026 12:11

Link do produktu: <https://biuroparts.pl/nowa-oryginalna-glowica-do-drukarek-epson-l3250-l3251-l3253-l3256-l3260-l3266-l4260-l4266-l5190-l5290-et2760-et2500-et2550-et4500-et4550-p-5668.html>



NOWA ORYGINALNA GŁOWICA DO DRUKAREK EPSON L3250 L3251 L3253 L3256 L3260 L3266 L4260 L4266 L5190 L5290 ET2760 ET2500 ET2550 ET4500 ET4550

Cena brutto	350,55 zł
Cena netto	285,00 zł
Numer katalogowy	DRUKPARTS-DUP-218722
Kod producenta	DUP-218722
Kod EAN	FA04000 FA04010 FA04040
Kod producenta oryginalny	FA04000 , FA04010 , FA04040 , FA04060

Opis produktu

NOWA ORYGINALNA GŁOWICA DO DRUKAREK EPSON L3250 L3251 L3253 L3256 L3260 L3266 L4260 L4266 L5190 L5290 ET2760 ET2500 ET2550 ET4500 ET4550 ...

UWAGA --> Fabrycznie zapakowana nowa oryginalna głowica EPSON przeznaczona do wymiany w serwisie drukarek.

Producent a tym samym pośrednik nie udziela gwarancji jeśli produkt nie jest montowany z oryginalnymi tuszami w autoryzowanym serwisie EPSON.

GŁOWICA PASUJĘ DO DRUKAREK EPSON

Epson L110
Epson L111

Epson L120

Epson L130

Epson L210

Epson L220
Epson L300

Epson L310

Epson L350

Epson L355

Epson L360
Epson L365

Epson L380
Epson L381
Epson L383

Epson L385

Epson L386
Epson L455

Epson L510

Epson L550
Epson L551

Epson L565

Epson L555
Epson L558

•

- **Epson ME303**
- **Epson ME401**

•

- **Epson WF-2010**
- **Epson WF-2510**
- **Epson WF-2520**
- **Epson WF-2530**
- **Epson WF-2540**

•

- **Epson XP-302**
- **Epson XP-303**

-
- **Epson XP-305**
 - **Epson XP-306**
 - **Epson XP-312**
 - **Epson XP-313**
 - **Epson XP-315**
 - **Epson XP-322**
 - **Epson XP-323**
 - **Epson XP-402**
 - **Epson XP-405**
 - **Epson XP-406**
 - **Epson XP-412**
 - **Epson XP-413**
 - **Epson XP-415**
 - **Epson XP-420**
 - **Epson XP-423**
 - **Epson EcoTank L 100**
 - **Epson EcoTank L 110**
 - **Epson EcoTank L 1300**
 - **Epson EcoTank L 200**
 - **Epson EcoTank L 210**
 - **Epson EcoTank L 300**
 - **Epson EcoTank L 310**
 - **Epson EcoTank L 350**
 - **Epson EcoTank L 355**
 - **Epson EcoTank L 361**
 - **Epson EcoTank L 365**
 - **Epson EcoTank L 380**
 - **Epson EcoTank L 382**
 - **Epson EcoTank L 385**
 - **Epson EcoTank L 386**
 - **Epson EcoTank L 455**
 - **Epson EcoTank L 485**
 - **Epson EcoTank L 486**
 - **Epson EcoTank L 550**
 - **Epson EcoTank L 555**
 - **Epson EcoTank L 565**
 - **Epson Expression Home XP-102**
 - **Epson Expression Home XP-202**
 - **Epson Expression Home XP-205**
 - **Epson Expression Home XP-212**
 - **Epson Expression Home XP-215**
 - **Epson Expression Home XP-225**
 - **Epson Expression Home XP-30**
 - **Epson Expression Home XP-302**
 - **Epson Expression Home XP-305**
 - **Epson Expression Home XP-312**
 - **Epson Expression Home XP-313**
 - **Epson Expression Home XP-315**
 - **Epson Expression Home XP-322**
 - **Epson Expression Home XP-325**
 - **Epson Expression Home XP-33**
 - **Epson Expression Home XP-402**
 - **Epson Expression Home XP-405**
 - **Epson Expression Home XP-405 WH**

-
- **Epson Expression Home XP-412**
 - **Epson Expression Home XP-413**
 - **Epson Expression Home XP-415**
 - **Epson Expression Home XP-420**
 - **Epson Expression Home XP-422**
 - **Epson Expression Home XP-425**
 - **Epson WorkForce WF-2010 W**
 - **Epson WorkForce WF-2510 WF**
 - **Epson WorkForce WF-2520 NF**
 - **Epson WorkForce WF-2530 WF**
 - **Epson WorkForce WF-2540 WF**
 - **Epson WorkForce WF-2630 WF**
 - **Epson WorkForce WF-2650 DWF**
 - **Epson EcoTank L3100**
 - Epson EcoTank L3108**
 - Epson EcoTank L3109**
 - Epson EcoTank L3110**
 - Epson EcoTank L3116**
 - Epson EcoTank L3118**
 - Epson EcoTank L3119**
 - Epson EcoTank L3150**
 - Epson EcoTank L3158**
 - Epson EcoTank L3160**
 - Epson EcoTank L3163**
 - Epson EcoTank L3210**
 - Epson EcoTank L3250**
 - Epson EcoTank L3260**
 - Epson EcoTank L4150**
 - Epson EcoTank L4160**
 - Epson EcoTank L4260**
 - Epson EcoTank L5190**
 - Epson EcoTank L5290**