

Dane aktualne na dzień: 08-10-2026 01:11

Link do produktu: <https://biuroparts.pl/oryginalny-encoder-enkoder-tasma-pasek-do-drukarek-epson-et2500-et2550-et2600-et2650-et4500-sx230-sx235w-sx435w-sx440w-sx445w-tx230w-tx235-t-p-5565.html>



ORYGINALNY ENCODER , ENKODER , TAŚMA , PASEK DO DRUKAREK EPSON ET2500 ET2550 ET2600 ET2650 ET4500 , SX230 SX235W SX435W SX440W SX445W , TX230W TX235 T

Cena brutto	36,89 zł
Cena netto	29,99 zł
Numer katalogowy	DRUKPARTS- DUP-216680
Kod producenta	DUP-216680
Kod producenta oryginalny	1548478 1593349 1564258 1593350

Opis produktu

ORYGINALNY ENCODER , ENKODER , TAŚMA , PASEK DO DRUKAREK EPSON ET2500 ET2550 ET2600 ET2650 ET4500 , SX230 SX235W SX435W SX440W SX445W , TX230W TX235 TX235W TX435W , NX230 , PX404A , XP-2100 ...

ENCODER PASUJE DO DRUKAREK EPSON JAK PONIŻEJ

Epson EcoTank ET2500 ET2550 ET2600 ET2650 ET4500

Epson Expression Home XP-101 XP-102 XP-103 XP-104 XP-105

Epson Expression Home XP-200 XP-201 XP-202 XP-203 XP-204 XP-205 XP-207 XP-211 XP-212 XP-213 XP-214 XP-215 XP-220 XP-222 XP-225 XP-231 XP-235 XP-245 XP-247 XP-255 XP-257

Epson Expression Home XP-302 XP-303 XP-305 XP-306 XP-312 XP-313 XP-315 XP-322 XP-323 XP-325 XP-332 XP-335 XP-337 XP-342 XP-343 XP-345 XP-352 XP-355

Epson Expression Home XP-402 XP-405 XP-406 XP-410 XP-411 XP-412 XP-413 XP-414 XP-415 XP-420 XP-422 XP-423 XP-424 XP-425 XP-430 XP-431 XP-432 XP-434 XP-435 XP-442 XP-445 XP-452 XP-455

Epson Expression Home XP-2100

Epson (CISS Models) L110 L111 L130 L132 L210 L211 L220 L222 L300 L301 L303 L310 L350 L351 L353 L355 L358 L365 L366 L386 L455 L456 L486 L550 L551 L555 L565 L566

Epson ME Office 535

Epson PX404A

Epson Stylus NX230

Epson Stylus SX230 SX235W SX435W SX440W SX445W

Epson Stylus TX230W TX235 TX235W TX435W